



## FAQ

Frequently asked questions

---

Password



**Wi-Fi**

## Password

---

**Question:**

How can I access my device, connecting it to Race Studio 3 via Wi-Fi, if I forgot the password?

**Answer:**

Wi-Fi configuration management is different according to the AiM device; it can be performed through the device or using RS3:

**Wi-Fi configuration managed through the device:    Wi-Fi configuration managed through RS3:**

- MXG/MXG 1.2
  - MXS/MXS 1.2
  - MXP
  - MXm
  - MXL2
  - MyChron5
- EVO5
- 
- To manage Wi-Fi configuration through AiM device: press Menu -> WiFi
    - select "WiFi Reset CFG" (for MXx 1.2 devices) / "Reset WiFi Config" (for MyChron5)
    - press "OK".
  - To manage Wi-Fi configuration through RS3 with EVO5 switched on and connected
    - double click on the device name
    - enter "WiFi and Properties " layer
    - delete the existing Wi-Fi password
    - transmit the configuration to the device.

Once these operations performed, connect again your device to the PC and set a new password.

**N.B.: RS3 asks for the password only if it has been set from another PC.**